




LIN AVIATION SERVICES
NEW SOLUTIONS FOR A NEW AVIATION

MMSP / SLP

SAN LUIS POTOSI

AEROPUERTO INTERNACIONAL PONCIANO ARRIAGA



ADDRESS:

Carretera a Matehuala, KM. 9.5 Ejido Maravillas C.P.
78341 San Luis Potosí, S.L.P. México

TELEPHONE:

+52 442 476 5348
+52 442 609 5000
+52 331 431 3668

OPERATIONAL HOURS

24 H

CUSTOMS AND IMMIGRATIONS

24 H

FUEL AVAILABLE:

AVGAS 100LL / 130LL
JET-A

FUEL PAYMENT METHOD:

Debit Card
Credit Card
ASA Fuel Release

FIRE CAT:

VII

TYPE OF SURFACE:

ASPHALT

PCN:

064FCXT

ELEVATION (FT):

6035

CAR RENTAL:

YES

EXECUTIVE TRANSPORTATION:

YES

GROUND AMBULANCE:

YES

CATERING

YES

ARRIVALS:

1. Expect ground control instructions for taxiing to GENERAL AVIATION
2. Crew and passengers' passports will be requested by one of our staff representatives to present them to Immigration authorities. Once released they will be handed back.
3. When passengers get off the aircraft, Customs, federal agents, and health-sanitation authorities will board to perform an inspection.
4. Passengers must walk into the General Aviation building to follow the CIQ processes. Please consider all luggage must be unloaded and cannot be inspected without owner's presence (Authorities usually take trained dogs to detect food or any other substances).
5. This process takes around 15 to 20 minutes depending on the number of operations happening simultaneously at the airport.

DEPARTURES:

1. Once in the General Aviation Building, crew and passengers' passports will be requested by one of our staff representatives to present them to Immigration authorities to be stamped and authorized for departure.
2. Once Immigration process is over, our staff representatives will take all luggage to Customs for inspection. When ready, all passengers will be able to walk through the metal detector and board the aircraft.
3. The aircraft will be at the departure spot already, no need to tow it anymore.
4. This process will take from 15 to 20 Minutes